

LIVE TO PLAY LIVE®



JIMDUNLOP.COM

DUNLOP MANUFACTURING, INC. P.O. BOX 846 BENICIA, CA 94510 U.S.A. TEL: 1-707-745-2722 FAX: 1-707-745-2658

92E03012781 REV.A

SC95 SIGNATURE CRY BABY WAH OWNER'S MANUAL

SC95 SIGNATURE CRY BABY WAH

POWER

The SC95 Cry Baby® can be powered by one 9 volt battery (accessed via the bottom of the pedal), a Dunlop ECB003 AC adapter (ECB003E in Europe) or a Dunlop DCB10 DC Brick power supply.

SETUP INSTRUCTIONS

- Run a shielded instrument cable from your guitar to the SC95's Instrument jack.
- Run another shielded instrument cable from the SC95's Amplifier jack into your amplifier input.
- Turn on the amplifier and begin playing.
- To turn the pedal on/off, push the toe of the pedal down until you feel a "click".
- By rocking your foot back and forth on the pedal, you can change the effect that the SC95 Cry Baby has on the tone of your instrument instantaneously.
- Blue LED's on both side's of the pedal indicate ON/OFF status.

SPECIFICATIONS

Inductor	Custom wound low noise 560 millihenry high "Q" torroid
Input Impedance	.7 MEG Ω
Output Impedance	<1 K Ω
Sweep range	340 Hz - 1.7 KHz
Signal To Noise	>102 dB A weighted
Bypass	Hardwire DPDT bypass
Effect on LED's	Located on both sides of pedal

Power Requirements +9 VDC @ <3 ma., 5.5mm x 2.1mm positive barrel & negative center or standard 9 volt battery.

