

# SUPREME

1972 JAPAN

Univox Super-Fuzz Replica

---

## CONTROLS

**VOLUME** - Controls overall output volume. Left is less, right is more.

**EXPAND** - Acts as a fuzz control. This is the same name that the original fuzz control had. Left is less, right is more.

## SWITCHES

**TONE** - Engages a mid scooped sound. The standard sound has a thinner mid hump sound. This is the original Tone switch from the Super Fuzz.

**MODE** - This is our modification to the circuit. It engages a mid-boost. It's much more noticeable on the scooped sound with the Tone switch engaged.

## JACKS

**INPUT** - If you are looking at the jacks from above the pedal, the input is on the right.

**OUTPUT** - If you are looking at the jacks from above the pedal, the output is on the left.

## POWER

Uses 9V DC Negative Center. Do not use more than 9V DC, or your warranty will be voided. The Supreme does allow for battery operation via a single 9V battery. Just loosen the two rear screws from the enclosure and the backplate will swing open. On the inside you will see a battery clip to install the battery into. Have fun!

**JHS PEDALS**